
### WWW.CHINA-GAUGES.COM

### sales@china-gauges.com

## Spring hammer 0.5J





#### 1.Introduction:

 $(1) IEC60068-2-75 \ Spring \ Impact \ Hammer \ Test \ Apparatus \ is \ strictly \ designed \ according \ to \ IEC60068-2-75 \ standard.$ 

(2) After applying the impact with the hammer, the products is examined with accessibility probes to determine access to chock, energy, and injury hazards. Built in exact accordance to IEC/EN/UL/CSA and other standards.

#### 2.Application:

Adjust the impact severity by rotating the knurled cap until the desired energy-value i s displayed. Pull the knob slowly out of the device until it locks in place. If moved too fast, the clamp may skip its arrester and will lock at its way back when the pulling-for ce declines. Hold the device horizontally at it's housing tube and press the (black) rele ase cone to the specimens plane of impact. The strike is automatically released when t he release force threshold is reached.

#### Impact energy:

Allowable error: ±10%

The weight of impact element: 250g±5g

The power: <10N

The whole weight: 1250g±10g

Impact energy error:

 $0.50J \pm 0.04J$ 

# WWW.CHINA-GAUGES.COM

## sales@china-gauges.com




Figure E.1 - Spring hammer test apparatus